




TYPE-C




POWER




RGB




RESET and BOOT




M2 3.5*5+1.2





GPIO_OUT




IMU




Micor-SD



LCD



ESP32-C6



ESP32-C6-LCD-1.3



ESP32-C6	QM18658	RGB	Micor SD	1.3inch-Touch-LCD	1.3inch-LCD	PIN-OUT
GPI00				T-INT		
GPI01						GPI01
GPI02	T_T1N1/NC					GPI02
GPI03	T_T1N2/NC					GPI03
GPI04			SD_CS			
GPI05			SD_MISO			
GPI06			SD_MOSI	MOSI	MOSI	
GPI07			SD_CLK	CLK	CLK	
GPI08		RGB				
GPI012						USB N
GPI013						USB P
GPI014				CS	CS	
GPI015				DC	DC	
GPI016						U0TXD
GPI017						U0RXD
GPI018	T-SDA			E-SDA		
GPI019	T-SCL			T-SCL		
GPI020						GPI020
GPI021				RES	RES	
GPI022				BL	BL	
GPI023						GPI023