





KEY





SD Card




LCD



Type-C



BAT



Power

ESP32-C6	SD Card	LCD	QMI8658	Other
BAT_ADC				BAT_ADC
IO1	IO1	IO1		
IO2	IO2	IO2		
IO3	IO3			
IO4	IO4			
IMU_INT1			IMU_INT1	
IMU_INT2			IMU_INT2	
IO7				
IO8				
BOOT				BOOT
IO12				USB_N
IO13				USB_P
IO14		IO14		
IO15		IO15		
ESP_TXD				ESP_TXD
ESP_RXD				ESP_RXD
ESP_SDA		ESP_SDA	ESP_SDA	ESP_SDA
ESP_SCL		ESP_SCL	ESP_SCL	ESP_SCL
IO20		IO20		
IO21		IO21		
IO22		IO22		
IO23		IO23		



ESP32-C6-Touch-LCD-1.47